
THE NINTH PANEL RULES

Display case for LEGO® set 72046

1 CHECK FOR FILM



Protective film may be present. It can be clear or coloured. Check both sides and remove any film before assembly.

2 CHECK YOUR PARTS




Match all the pieces to the parts sheet before you start.

3 GENTLE TIGHTENING




Slotted (flat-head) hand screwdriver, not included. A screwdriver head that snugly fits the screw head makes assembly easier than an ill-fitting one. Do not over-tighten.

4 FOLLOW THE PURPLE



Purple shows the part being added or featured in the step.

5 SMOOTH FACE FORWARD



The four cubes at the front of the case must have their smooth, hole-free side facing the front panel.

BEFORE YOU START


- Printed panels: remove protective film if present. Do not peel or scrape the printed artwork. **The colour side faces forward.**
- Peeling tip: if film is present, lift a corner with a fingernail and peel slowly. Do not use sharp tools.
- Part labels match the parts sheet; letters show the step order. Artwork colours are simplified in the drawings.

NINTH PANEL


CHECK YOUR PARTS




Part 1
Lid
1×




Part 2
Front panel
1×



Part 3
Printed border
1×



Part 4
Printed grid
1×




Part 5
Sides: use either
2×



Part 6
Clear bottom
1×



Part 7
Black base
1×



Part 8
Rear wall mount A
1×



Part 9
Rear wall mount B
1×




Part 10
LEGO® holder crossbar
1×




Part 11
LEGO® holder stem
2×



Part 12
Game card insert hooks
4×



Part 13
Slotted screws
26×



Part 14
Silver cubes
12×



Part 15
Corner feet
4×

Parts 8 / 9 are a mirror pair.

Magnets, including all four in the front panel, and LEGO® studs are already fitted. Leave them in place.

NINTH PANEL ASSEMBLY

A




Fit feet to the face WITHOUT the white outline. Keep the four large holes clear.



White outline = top

B



Part 14 2×




Flat face towards front of case


Part 1




Part 13 6×



C




Part 14 2×




Flat face towards front of case


Part 13 6×




D



Part 13 4×




E




NINTH PANEL ASSEMBLY


F



G




Part 13 4×




H






Part 13 6×




I






J






K






NINTH PANEL ASSEMBLY


L




M




N




Part 12 — 4×



O




P




TIP

Align the four pre-fitted magnets with the flat cube faces.
Fit gently; no screws here.

Magnets 4×




Q



White outline up / feet underneath

CASE CLOSED.



For LEGO® set 72046

INSERT PHONE TO CONTINUE.

Scan here for digital instructions.

LEGO® is a trademark of the LEGO® Group, which does not sponsor or endorse this product.